



END USER INSTRUCTIONS - READ BEFORE USE

PRODUCT NAME:

V-Lite™ Multi-Mode

PROGRAMMING INSTRUCTIONS


PART NUMBER:

VL-XX012V

NOTE:

V-Lite™ Default Mode is Mode 5 “Demo Mode”

Programming Mode will time out after 30 secs. of no activity



MODE	PRESS 1x	PRESS 2x	PRESS 3x	PRESS 4x	PRESS 5x
1	ON	OFF			
2	BLINK	OFF			
3	ON	BLINK	OFF		
4	¼ POWER	½ POWER	¾ POWER	MAX POWER	OFF
5* demo mode	ON (30 s)	BLINK (30 s)	OFF		

* Mode 5 is Demo Mode and times out after 30 seconds. It is not intended for regular use.



Press/hold Power Button for 5 secs. to enter programming mode. LEDs will flash rapidly indicating programming mode.



Momentarily press the button to cycle through V-Lite™ modes. All LEDs will blink. The number of blinks between pauses indicates mode (see chart below). Each press of the button cycles to the next mode.



Cycle to desired mode, press/hold button for 5 secs. to lock in mode. All LEDs turn on for 2 secs. then turn off to indicate mode has been programmed.



Turn V-Lite™ on and cycle through mode to ensure mode was programmed.

OPEN CAMERA TO
VIEW USER INSTRUCTIONS OR VISIT
[WWW.SSPGEAR.COM/
END-USER-INSTRUCTIONS](http://WWW.SSPGEAR.COM/END-USER-INSTRUCTIONS)

